



ATTENTION!
Only be used with
Transport-PC (TP 5103)
and Dialer
as from Version 6.0

ADVISOR[®]

CD7203

Programming Manual

This manual must be used in combination with the
CD95/15003 Programming Manual.

Software from Version: V6.0

COPYRIGHT

© SLC BV 1997. All rights reserved. No part of this publication may be reproduced, transmitted, stored in a retrieval system, or transmitted in any form, or by any means - electronic, photocopying, recording, or otherwise - without the prior written permission of SLC BV.

DISCLAIMER

SLC BV makes no representations or warranties with respect to the contents hereof and specifically disclaim any implied warranties of merchantability or fitness for any particular purpose. Further SLC BV reserve the right to revise this publication and to make changes from time to time in the contents hereof without the obligation of SLC BV to notify any person of any such revision.

MENU CONTENTS

How to use this manual

All options in the CD7203 are also used in the CD95/15003. Consequently, all the menu items available in the CD7203 are listed here, but they are only explained when they differ from the CD95/15003. At a later date a complete manual for the CD7203 will be issued. In the meantime, this manual must be used in combination with the CD95/15003 programming manual.

The menu items are listed in this manual and in the CD95/150 programming manual in the order of their quick codes (as shown in the programming maps). In other words, an item's quick code is its section heading number in the "Menu Contents" chapter of the manual.

Note: The page numbers shown below refer to those of the CD95/15003 programming manual.

What is a "Quick Code"

With this method you simply enter the number(s) shown in the menu items' boxes of the programming map and the display will immediately select the item for you. This method is much quicker than scrolling through the items because you press fewer keys. The quick code numbers do not appear on the keypad display. They are shown in the programming map to help you locate an item.

For example, if the keypad display is showing "Timers" and you want to go to "Zone Type", press consecutively the buttons 4 and 1 (the Quick Code) to jump directly to this item.

Page No.

1. Maintenance menu	19
1.1. Show the engineer log	19
The engineer memory can contain up to 150 events.	
1.2. Test the outputs	
1.3. Show the open zones	19
1.4. Walk testing of zones	19
This option is called the "Standard walk test" in the CD95/150.	
Allows any zone to be tested. Opening a zone will activate the 'Internal bell' output for 3 seconds. The 'Walk Test' and 'Memory' outputs for detectors with EAM are also controlled by this option. The 'Fire Reset' output is activated 10 seconds after the zone is activated. You can therefore test detectors, such as breaking glass or fire detectors, without needing to reset every detector manually.	
1.5. Request extended access	20
1.6. Mask lid tamper	20
1.7. Test the LED's on the keypads	20
2. Time settings	21

2.1. Entry times	21
2.1.1. Entry time 1	21
2.1.2. Entry time 2	21
2.2. Exit time	21
2.3. Abort entry time.....	21
2.4. Bell menu	22
2.4.1. Bell cut-out time	22
2.4.2. Bell delay.....	22
2.4.3. Stop 'Internal bell' with 'External bell'	22
2.4.4. Communicator 'alarm' restore with external bell	22
2.5. Options for double knock	27
2.5.1. Double knock time window	27
2.5.2. Double knock open time	27
2.6. Time.....	27
2.7. Date and text menu.....	28
2.7.1. Date.....	28
2.7.2. Alternate date/text.....	28
2.7.3. Enter the alternating text.....	28
2.8. Settings for summer time/winter time	28
2.8.1. Summer time setting.....	28
2.8.1.1. Date	28
2.8.1.2. Time.....	28
2.8.2. Winter time setting	28
2.8.2.1. Date	28
2.8.2.2. Time.....	29
2.8.3. Use summer time.....	29
3. Users and codes menu.....	30
3.1. Program the codes and the options	30
Refer to the programming map for an overview of the user attributes.	
The total number of user codes is 16.	
3.2. Program the user name	32
3.3. Set the options for the engineer code	32
3.3.1. Re-programme the an engineer code.....	33

3.3.2. Authorisation for engineer access by user code	33
3.4. Up/Download user code 1	33
3.5. Up/Download user code 2	33
3.6. Enable show open zones (to the user)	33
3.7. Also show the technical zones	33
3.8. Enable key switch error display	33
4. Zone menu	34
4.1. Program the operation of a zone	34
Refer to the programming map of the CD72 for an overview of the zone types and attributes.	
4.2. Program the zone attributes	37
Refer to the programming map of the CD72 for an overview of the zone types and attributes.	
4.3. Program the shock zones	
(INERTIA ZONES) The following zone inputs can be programmed to accept GS 600 series inertia shock sensors directly, when already programmed as ALARM or EXIT/ENTRY type.	
On the CD72, zones 1 to 4 can be programmed as an inertia zone, gross attack 1 to 9 (1 maximum sensitivity), pulse count 2 to 9.	
To program these facilities, select the SHOCK ZONES option from the ZONES menu.	
The above sequence can also be used to check values already programmed for existing shock sensor zones during servicing. For full details regarding the installation/specification of the sensors themselves, consult the information manual that accompanies the units.	
When an inertia zone is put into walk test (menu 1.4.), the size of the shock level registered on the structure is displayed together with a "W" which flashes to indicate the zone is in "Walk Test".	
If an inertia zone causes an alarm activation, then the value of any "Gross" level responsible for an alarm will be stored in the ENGINEER log replacing the month part of the date stored.	
Since this level can again be simulated during walk test of the zone by the engineer, this provides an advantage when ascertaining the cause of any particular inertia zone activation.	
4.4. Program the zone name	38
4.5. Program the zones for dual or alarm loop	38
5. Program outputs and remotes	40
5.1. Program the outputs	40
Refer to the programming map of the CD72 for an overview of the output types.	

5.2. Install connected remotes	44
5.3. Assign remotes to an area	44
5.4. Show the zones of a remote.....	44
5.5. Assign display/keypad to an area.....	44
6. Settings for a split system	46
6.1. Number of areas	46
Up to 2 areas can be programmed	
Default: 1 Areas	
6.2. Number of common areas.....	46
Program “1” if a common area is used, “0” when no common are is used.	
Default: No common areas	
6.3. Assign zones to an area.....	46
A zone can be assigned to Area 1 “A1”, Area 2 “A2” and a common area “C1”.	
Default: All zones linked to area 1	
6.4. Assigning keypads to an area - enable/disable	46
Once this option is ‘On’, the operation of an area will only be possible from keypads that are assigned to the area via menu 5.5 (Area -> Rkp).	
7. Miscellaneous menu	47
7.1. Arm/disarm options	47
7.1.1. User walk test	47
With this option you determine whether a user is able to do a walk test when arming the system.	
If a zone is open when arming, the user will not be able to arm the system and the internal siren will be activated for 2 seconds when this zone is closed. Each time an “Exit/Entry” or “Alarm” zone is opened and closed the internal siren will be activated.	
7.1.2. Forced arming options	49
7.1.3. Options for auto-rearm.....	49
7.1.4. Display options.....	50
7.1.4.1. Arm status on the display	50
7.1.4.2. Display light always on.....	50
7.1.5. Options for buzzers and bells.....	50
7.1.5.1. Exit fault on internal bell or internal and external bell	50
7.1.5.2. Buzzer during exit time	51
7.1.5.3. Buzzer during the entry time	51
7.1.5.4. Buzzer during partguard exit time	51
7.1.5.5. Buzzer during partguard entry time.....	52
7.1.5.6. Internal and External Bell activation when system is Disarmed	52

7.1.6. Last door setting.....	52
7.1.7. Fast arm/disarm	52
7.1.8. Old or new user interface.....	52
7.1.9. Arming possible in the event of a line fault	53
7.2. P.A. alarm options.....	53
7.2.1. Silent P.A. alarm	53
7.2.2. Silent P.A. in the event of a line fault	53
7.2.3. P.A. at keypads	53
7.2.4. P.A. alarm always active	53
7.3. Partguard arming and chime options.....	53
7.3.1. Partguard arming with exit time	54
7.3.2. Access zones converted to entry/exit zones in partguard.....	54
7.3.3. Central station reporting in partguard.....	54
7.3.4. Automatic switch on of chime at disarm	54
7.3.5. Chime activates internal bell	54
7.4. Engineer reset menu.....	54
7.4.1. Engineer reset only with reset code or code and F.T.C.....	55
7.4.2. P.A. alarm causes engineer reset.....	55
7.4.3. Tamper causes engineer reset.....	55
7.4.4. Engineer reset after an alarm or tamper during arm period.....	55
7.4.5. Clear engineer reset.....	55
7.5. Warnings menu.....	55
7.5.1. Activate the buzzer in the event of a mains failure.....	55
7.5.2. Activate the buzzer on-line fault	55
7.6. Factory settings menu.....	56
7.6.1. Return the panel to default settings	56
7.6.2. Switch on engineer lock	56
7.7. External light menu	56
7.7.1. Duration of external light	56
7.7.2. External light option during exit time	56
7.7.3. External light options during an alarm.....	57
7.7.4. Reset the external light with the external bell.....	57
7.8. Entry/exit and access zones included in 'System Clear' output	57
8. Dialler menu	58

8.1. Dialler Menu	58
8.2. Return the dialler to default settings	58
8.3. Make a line connection.....	58
9. Printer menu.....	59
9.1. Print a test line on the printer	59
9.2 Print panel menu.....	59
9.2.1. Print the complete programming.....	59
9.2.2. Print the user names and options	59
9.2.3. Print the zone programming.....	59
9.2.4. Print the outputs	59
9.2.5. Print all other functions.....	59
9.3. Print the engineer's log	60
9.4. On-line printing.....	60
9.5. Use the IBM2/Standard character set	60
9.6. Settings for the RS232 port.....	60
9.6.1. Change the baud rate	59
9.6.2. Handshake enable	59
9.6.3. Line width.....	59

PROGRAMMING MAP CD7203

Note: The quick code numbers in front of each menu item are also the section numbers in the Menu Contents chapter of the CD95/15003 Programming manual, i.e. the quick code for 'Digi Cutout' is 2 4 4, which is explained under section number 2.4.4 in the Menu Contents chapter.





